


Integrated LED Display



All pictures in this user manual are for reference only. Actual product may vary

Product User Manual

Table of Contents

I . Product Introduction	3
II. Function Introduction	8
III. Function Menu Introduction	16
IV. Menu Introduction	18
V Quick Troubleshooting	28
VI. Special Statement	29

Warning

It is a Class A product and operation of this device in a residential environment may cause radio interference.

There is a high possibility that the device will be damaged and cannot be recovered due to ignoring the warning.

- 1) Do not invert or throw the device during handling and storage;
- 2) Do not tilt and collide the device during installation to avoid scratches;
- 3) Do not drench or soak the device;
- 4) Do not close the air outlet of the air conditioner to the display;
- 5) Do not place or use the display in the environment with volatile, corrosive and flammable chemicals;
- 6) Do not use the product at the humidity above 80% or in outdoor rainy environment;
- 7) Do not use water or chemical solvents to clean display device;
- 8) Do not use electrical accessories not certified by the device manufacturer;
- 9) Ensure that the display and auxiliary equipment are correctly and reliably grounded before use;
- 10) In case of abnormalities, such as peculiar smell, smoke, electric leakage and abnormal temperature, please cut off the power supply immediately, and then contact professional;
- 11) This equipment has two input sockets, which must be disconnected at the same time to disconnect the power supply from the equipment;
- 12) Connect it to 100-240V AC power supply;


◆Caution!

The probability of not getting the best display due to ignoring the precautions is extremely high.


- 1) Wear anti-static gloves and anti-static wrist strap when installing and repairing the product;
- 2) Good ventilation on the back of the display must be considered when designing the cooling solution;
- 3) The storage environment of the display shall be ventilated and dry, and the humidity shall not exceed 85%RH;
- 4) Under normal circumstances, it must be ensured that the display is powered on at least twice a week, and each light-up time is not less than 2 hours;
- 5) If the display is installed in the seaside, saline areas, the areas with sulfurized gases, near the fume exhaust in kitchen, and the indoor and outdoor sites with large temperature difference, it may cause equipment failure and affect the service life. If it is unavoidable, please consult our professional and technical personnel;
- 6) This product is only suitable for safe use at altitudes below 5000m;
- 7) The operating ambient temperature of the display must not exceed - 10 ~ 40 °C;

I . Product Introduction

(1) Product appearance




Front of the product



Back of the product

* Product back view diagram using the 135-inch product as an example.

(2) I/O Ports



NO.	Description	NO.	Description
1	USB3.0	6	USB3.0
2	IR	7	HDMI2.0 input
3	dual-color indicator light(red/blue)	8	HDMI1.4 input
4	RS232	9	WAN
5	AUDIO OUT	10	Standby/Wake up button

(3) Remote control description


Button Icon	Introduction	
	Standby/Wakeup	
	Up	
	Down	
	Confirm	
	Left	
	Right	
	Voice+	
	Voice-	
	Back	
	BrightnessAdjustment	
	Menu	
	MainInterface	

(4) Interface description

The number and types of ports on the device are subject to the actual product.

The descriptions in this manual are for illustrative purposes only.


HDMI input connection



Connection instructions:

1. Connect to the device with HDMI output (such as a computer) using an HDMI cable;
2. Press the channel switch button (on the display or remote control) to switch to the HDMI display channel.


USB input/TYPE-C input



Connection instructions:

1. Connect USB flash drive, mouse, keyboard, etc., to the USB/TYPE-C ports;
2. After connecting to the USB/TYPE-C ports, the mouse and keyboard can be used directly;
3. To view the contents on the connected USB flash drive, navigate to the file explorer in the system main interface.

Audio signal output




Connection instructions:

1. Connect one end of the audio cable to the 3.5mm audio output port and the other end to an amplifier, speaker, headphones, etc.;
2. The remote control can be used to control the volume of the audio output.

II. Function Introduction


1. Main interface



Home Page

Quick screen sharing guided by on-screen prompts.

2. Wireless screen mirroring



Screen Share

(1) Mobile APP


- ① Connect to the screen mirroring hotspot;
- ② For Android users, scan the QR code to download the ScreenShare mobile app. In the app, find the [Screen Mirroring] module for screen mirroring (Refer to the ScreenShare mobile app user manual).
- ③ Apple devices use Airplay for screen mirroring.

(2) Computer client

- ① When using it for the first time, you need to connect the wireless screen mirroring device to the USB port of the large screen for pairing, then remove it after successful pairing;



- ② Connect the wireless screen mirroring device to a computer with a PC system and run the screen mirroring program;




③ After the program runs successfully, press the wireless screen mirroring device to achieve screen mirroring.

(3) Mac Airplay

- ① Connect to the device hotspot via WiFi on your MAC system phone or computer, and enter the password to connect to the hotspot;
- ② Use the Airplay feature in the MAC system for screen mirroring.

3. File Explorer




File Explorer

(1) File explorer: Allow users to browse and operate files.

- Display mounted USB drive
- File browsing by category (Pictures, Videos, Documents, Music)
- Switch file display mode


➤ Open menu



File Explorer Menu


- ① Cancel: Cancel operation
- ② Multi-select: You can select multiple files at the same time for operation
- ③ Select all: Select all files
- ④ Copy: Copy files
- ⑤ Cut: Cut files
- ⑥ Paste: Paste files
- ⑦ Delete: Delete files
- ⑧ Sort: Support sorting files by name, time, size.

(2) Videos



Video file list


- ① Click on the corresponding disk to view all video files on the disk
- ② Click on a video file to play it



Video Playback Interface


- | | | | |
|-------------|------------------|--------------|---------------|
| 1: Playlist | 2: Fast backward | 3: Previous | 4: Play/Pause |
| 5: Next | 6: Fast forward | 7: Play mode | 8: Volume |

(3) Music



Music file list


- ① Click on the corresponding disk to view all music files on the disk
- ② Click on a music file to play it



Music Playback Interface


- | | | | |
|-------------|------------------|--------------|---------------|
| 1: Playlist | 2: Fast backward | 3: Previous | 4: Play/Pause |
| 5: Next | 6: Fast forward | 7: Play mode | |

(4) Gallery



Picture file list

- ① Click on the corresponding disk to view all picture files on the disk
- ② Click on a picture file to view it in full screen



Picture Preview

- | | | | |
|----------------|------------------|--------------------|--------------|
| 1:Previous | 2:Next | 3:Zoom in | 4:Zoom out |
| 5:Actual | 6:Fullscreen | 7:Rotate clockwise | 8:Settings |
| 9:picture list | 10:Time interval | 11:Animation mode | 12:Auto-play |

4. Pivot

MAXHUB Pivot
Not enroll yet
CODE: 8FCFTAC3

Welcome to MAXHUB Pivot

This device management system enables remote control of devices and publishes information for businesses, schools, and other organizations.

Welcome to register for an account to use MAXHUB Pivot.



Enroll device

Pivot

Pivot: Allows remote access and control through Pivot. See the Pivot User Manual for detailed operations.

III. Function Menu Introduction

Access the menu using the remote control or the options button on the control panel:




1. Brightness




Open the brightness adjustment box, you can adjust the brightness value using the "Up and down arrow keys"

2. Volume



Open the volume bar, you can adjust the sound volume using the "Up and down keys".


3. Color



Open the color adjustment menu, where you can switch between scene modes and adjust brightness, saturation, color temperature, contrast, and tint.


4. Input source

Open input menu: Switch input source.




IV. Menu Introduction

Click on "Settings" to access the settings menu page.




1. Network


(1) Ethernet: Turn on or off the wired network.



(2) Wireless Network: Turn on the wireless network to automatically search for available networks, click on a network to connect.




(3) Wireless Hotspot



- ① Hotspot Switch: Turn the hotspot on or off.
- ② SSID: Change hotspot name.
- ③ Hide SSID: Show/Hide hotspot. When the hotspot is hidden, it is actually turned on, but other devices will not be able to detect it.
- ④ Enter password: Change password.

(4) Bluetooth Settings: Turn on or off Bluetooth;




After turning on Bluetooth, you can connect to Bluetooth devices within the

search range.

2. General


(1) Sound



① Volume: Adjust the volume level.

② Speaker: Selecting the corresponding device can specify where the sound is output from.


(2) Display




① Image mode: Set image mode.

- ② Brightness: Set brightness.
- ③ Contrast: Set contrast.
- ④ Saturation: Set saturation.
- ⑤ Color temperature: Set color temperature.
- ⑥ Color hue: Set color hue.

(3) Personalization




- ① Edit home page: Set layout & wallpaper.




- ② Boot animation: Set power-on logo and power-on animation.

(4) Device Management




- ① Device Name: Custom equipment name.
 - ② USB shield: Set whether USB devices should be loaded.
 - ③ Remote wake-up service: Turn on/off the remote wake-up service.
 - ④ CEC: HDMI CEC switch.
 - ⑤ KeyPad Lock: Customizable power button lock functionality
 - ⑥ Automatic maintenance: The integrated machine performs regular dehumidification maintenance.
 - ⑦ Channel automatically jumps: Turn on/off channel auto-jump.
 - ⑧ Boot fixed channel: Set the signal source displayed when power on.
- (5) Standby mode: Set to enter sleep mode and standby mode.




① Sleep time: Choose whether to enter sleep mode based on usage habits.

② Standby time: Choose whether to enter standby mode based on usage habits.

(6) Timer Switch: Set the scheduled power on/off according to actual usage needs.




(7) Roll Caption: Set the text content, scrolling mode, font size, text color, and background color.




3. System


(1) Language and Input: You can choose the language and input method.




(2) Date and Time: You can reset the time and date.




(3) Restore: Clear all data in the device.



(4) System upgrade: Check for updates.



(5) About: Display device related information.



V Quick Troubleshooting

(1) Part of the display is not lit after power on

- 1>Check whether the Ethernet cables inside the cabinets are in good contact;
- 2>Check whether the power cables inside the cabinets are in good contact.

(2) Wireless screen mirroring not working

- 1>Check if the wireless screen mirroring device is securely inserted;
- 2>Check if the wireless screen mirroring device is paired. To pair, insert the wireless screen mirroring device into the USB port of the integrated machine, wait for the prompt, and confirm the successful pairing;
- 3>Check if the computer has the required driver software installed. If the screen mirroring device is inserted into the computer's USB port and automatic installation doesn't occur, manually go to "My Computer", locate the drive corresponding to the screen mirroring device, and double-click to install the driver.

(3) Indicator light is not on

- 1>Check whether the power supply is normal;
- 2>Check whether the power switch of the system is turned on.

(4) No image on the display after connecting its to the computer with HDMI cable

- 1>Check whether it is currently on HDMI channel;
- 2>Check whether the HDMI cable on the system and the external computer falls off or is defective.

VI. Special Statement

Intellectual Property Declaration: The hardware design and software program of this product are protected by copyright. Reproduction of this product and the contents of the manual without our authorization will be subject to corresponding legal liability.

The contents and pictures in this manual are for reference only and do not constitute any kind of commitment.

The company reserves the right to modify and change the appearance design of the product without prior notice.

Note: HDMI, and HDMI logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.